



## CRACKED MONITOR

The Standard Concrete Crack for monitoring displacements in two directions (top-bottom/left-right). Simply stick or glue over the two piece crack together first and make sure the crack center crosshair alignment, and then fasted it to the wall with screws and expansions screws. The crack monitors displacement will be shown by a movement of the cross hairs over the measuring scale (40 x 20 mm). Size will be 148 x 30 x 6.5 mm, also will offer with a reading and writing record sheet together.

### Technical Specifications :

Model Number	NL 7068 X / 001
Material	ABS
Vertical Measurement	$\pm 1$ mm ( $\pm 0.04$ " ) tick marks on X-Y axes; $\pm 0.5$ mm ( $\pm 0.02$ " ) discrimination
Horizontal Measurement	$\pm 20$ mm ( $\pm 0.79$ " ) horizontal and $\pm 10$ mm ( $\pm 0.38$ " ) vertical range
Product Dimension	140 x 30 x 7 mm
Weight	45 g

